

! WARNING

Installation of asm-autocontrol is only allowed to the anchor point “C”!

Vehicle Reference List SCHROTH asm-autocontrol				
Make	Model	Mod.	install retractor to	
Model	No.	Year	anchor point C	D <sup>Y</sup>
AUDI				
4000	81	80-87	+	-
5000	43	80-83	+	-
Coupé, GT	85	82-87	+	-
BMW				
1602-2002, not convertible		68-76	+	-
3-series	E21	77-83	+	-
3-series				
-sedan		86-91		
Mod.-No.: AB54/64, AE54/64, AD23, AA23, AB03, AB93, AE03, AF93, AJ93			+	-
with <b>un</b> covered anchor point C				
5-series	E12	72-77	+	-
	DK73, DK83, DC74, DC84	82-88	+	-
-M5	DC93	82-88	+	-
6-series	EC74, EC84	76-89	+	-
-M6	EE14	76-89	+	-
7-series	FH74, FG24	78-86		
with <b>un</b> covered anchor point C			+	-
DAIHATSU				
Rocky	FF31, FF32	90-	+	-
GEO				
Metro	MS2, MR2	89-94	+	-
Tracker	E18, J18	89-		
seat with integrated headrest			S	-
seat without integrated headrest			+	-
HONDA				
Civic Coupé, only 2-door	EJ222, EJ122	93-	+	-
JEEP CHRYSLER				
Wrangler <sup>17)</sup>	Y19, Y29	92-	S	-
MAZDA				
323	BF22, BF23	87-89	+	-
929	HC22	88-91	+	-
MITSUBISHI				
Cordia	F34,F44,F54,F64	83-87	+	-
NISSAN				
Sentra, only Coupé	B24	87-90	+	-
200 SX, only hatchback	S26	-88	+	-
version				
Stanza	T21, T23	86-89	+	-
Maxima	U11	86-89	+	-
Pathfinder	D14,D16,D17	87-	+	-
RENAULT				
R5, LeCar		76-83	+	-
SUBARU				
Justy, only 2-door	A72, A73, A83	87-	+	-
SUZUKI				
Suzuki Swift, only 2-door	AC	90-94	+	-
Suzuki Sidekick, only with short wheelbase	TC,TA,TD	89-	+	-
TOYOTA				
Starlet, only version without rear side vent window		81-84	+	-
Corolla	E82E, E83E, E84E	-87	+	-
Celica, not convertible				
Mod.-No.: T63C-T67C, T64L-T67L, T68M		86-89	+	-
Camry		87-91	+	-
Landcruiser, o nly with short and middle wheelbase		85-	+	-
4-Runner, only 5-door	N27V,N37W	89-	+	-
VOLKSWAGEN				
Beetle	11	60-79	+	-
Rabbit	17	75-84	+	-
Jetta I		80-84	+	-
Scirocco I	53	75-81	+	-
Golf	17, 1G	85-92	+	-
Jetta II	16, 1G	85-92	+	-
Golf IV, 2-door <sup>27), 35)</sup>	9B	02-	+	-
Jetta <sup>27)</sup>	9M	02-	+	-
Dasher, only 2-door	32	76-81	+	-
Scirocco II	53	82-88	+	-
Corrado	50	90-95	+	-
VOLVO				
240, 260, not station wagon	DL, GL, 240	75-93	+	-

## Legend to Vehicle Reference List

### Heed all Indexes!

### Symbols and #'s must be followed !

- Retractor **must not** be installed to this anchor point.
- + Retractor can be installed to this anchor point without vehicle alteration.
- S Stock seat not approved. For ins tallation of retractor to this anchor point, use only special seats, tested and approved by SCHROTH.  
For SCHROTH tested and approved special seats see list below.
- Y Installation of the retractor to anchor point "D" requires adapter (Part.-No. 01103). Must be purchased in addition.

Installation at anchor point "D": An approved seat (stock seat or special seat) required.

- 10) Index "S" do not refer to vehicles equipped with RECARO front seats ("sport seats").
- 12) Special side belt [Part No. 0010 X (X refers to webbing color)] for center lap belt installation **strictly** required. Must be purchased in addition.
- 15) Installation of retractor to anchor point "E" instead of "D".
- 17) Two adapters [Part No. 0015 X (X refers to webbing color)] are **strictly** required and must be installed at **both** sides of the lap belt. Must be purchased in addition.
- 19) Because of needed inner anchor point modification, installation kit (Part No. 00095) is **strictly** required. Must be purchased in addition.
- 27) To avoid release of the pyrot echnic seat pretensioning devices the battery has to be disconnected 10 minutes before starting installation.
- 35) If stock 3 -point belt should be removed from the car **never** remove stock seat belt buckle as there is a safety device included (VW-description: lunar module) which **never** must be removed from the car.

## List of Approved Special Seats

### COBRA SUPAFORM

Cobra S, Instyle/LS, Montreaux

### CORBEAU EQUIPE

Avanti Recliner, GTB Recliner, GTS Recliner;

### FLOFIT

Flofit-Sport

### KEIPER RECARO

Orthopäd (Orthopedic), Designer Touring (design touring), Idealsitz SR, L, LX, LS 84, CS 84, CSE, T -Line, Designer Sport (design sport), C-Classic, TX, N, LS, CT, Variomed, A 8

### KÖNIG

K330/370, K430/470, K530/570, K630/670, K730/770, K830/870, KS400/4000/700, CP400/4000/700, P700, RL200, CL200/400, RS/RSL 4400/8800

Be sure to contact your local Cobra, Corbeau, Flofit, König or Recaro dealer for information regarding seats recommended for the make, model and model year of your car.

### MDI Inc.

3 First Avenue  
Peabody, MA 01960  
Toll Free(888) 536-8550  
Phone(978) 532-1145  
Fax(978) 532-2016

Our Service Number  
(800) 884-BELT  
guides you to your nearest dealer.