

INSTALLATION & OPERATING INSTRUCTIONS

VW/Audi Quick Fit Rallye 4 Harnessbelts



**Safety
through
Technology**

Edition 05/2003

**Patents granted in
Patente wurden erteilt in**

DE	3 735 077
GB	2 211 070
I	1 207 344
USA	4 854 608

Installation Operating Instructions	01–12
Questions about Installation	02–03
Package Contents	04
Installation	04–06
Operating	06–09
Care and Maintenance	09–10
Accessories and Spare Parts	11



This manual contains important information as well as DANGERS, WARNINGS and SAFETY INSTRUCTIONS regarding the proper installation, effective use and maintenance of the SCHROTH harnessbelt. Please be sure to read and thoroughly understand its contents before beginning installation and before using the system. Follow all instructions and Safety Instructions carefully and be especially sure to heed all Dangers and Warnings.

Always keep this manual in your car for reference and be sure to leave it with the car if you sell it with the harness belt system installed.

Important information and instructions in this manual are shown:

DANGER

DANGER deals with important points about the installation of the SCHROTH harnessbelt. Ignoring these warnings will create serious danger that can lead to serious personal injury or death.

WARNING

WARNINGS deal with important issues about installation, use, misuse or modification of the SCHROTH harnessbelt.

Ignoring these Warnings will significantly reduce the performance of the harness belt system. This can result in serious personal injury or death during an accident.

SAFETY INSTRUCTIONS

?? Safety Instructions contain important hints to help you effectively install, use and maintain the SCHROTH harnessbelt.

Always carefully read and follow the information in this manual, especially those highlighted as above.

INSTALLATION & OPERATING INSTRUCTIONS

Approvals:

VW/Audi Rallye 4 Harnessbelts

USA:

Tested in accordance with applicable provisions of FMVSS 209

US model tested and inspected by



Made in Germany by:

SCHROTH Safety Products GmbH

Postfach 24 40

59714 ARNSBERG

GERMANY

Phone + 49 - 29 32 - 97 42-0

Fax + 49 - 29 32 - 97 42-42

Imported by:

USA: **MDI/Schroth**

3 First Avenue

Peabody, MA 01960

Toll Free (888) 536-8550

FAX (978) 532-2016

Other Countries: see

www.schroth.com

Phone (978) 532-1145

Congratulations!

With the purchase of this SCHROTH asm harnessbelt, you have chosen a sophisticated restraint system, which represents a further advance in harness restraint technology. Extensive research, testing and field experience has shown it to offer, when properly installed and worn, high levels of protection in head-on collisions.

SCHROTH VW/Audi specific asm-Rallye 4 Series harnessbelts are only intended for installation at the left and right outboard front seating positions of designated VW/Audi model passenger cars which have been specifically evaluated by SCHROTH engineers for anchor point locations and suitability of available front seats.

Before attempting installation, please first answer the following questions and carefully follow the instructions which accompany them.

WARNING

Restraint systems can only offer protection if they are properly installed and used.


To assure proper function, your car must meet special technical requirements.

Before installation of SCHROTH harnessbelt, please answer a few very important questions to make sure the SCHROTH harnessbelt system can be properly installed and effectively used in your car..

1. Does your vehicle appear on the included reference list?
YES ☐ NO ☐



2. Have you maintained your original equipment factory provided seats and factory harness mounting points?
YES ☐ NO ☐




4. Do you have a left belt for the driver's side and/or a right belt for the passenger's side? (See illustrations on page 4.)
YES ☐ NO ☐



If your answer to any of these 4 questions is [NO], do not install the SCHROTH harnessbelt system.

If you have answered ALL questions with [YES], you may install the SCHROTH harnessbelt system in your car.

Please remember that installation procedures will require you to perform a variety of operations requiring familiarity with tools and mechanical procedures. If you have any doubt about your ability to properly install the SCHROTH asm harnessbelt system, take this manual and all parts supplied to a competent mechanic for installation.



This SCHROTH asm harnessbelt is only suitable for adults on front outboard seating positions.

SCHROTH asm harnessbelts are not intended or suited for use by children under 12 years of age, or persons who weigh less than 88 lbs (40 kg) or those who are less than 4'11" tall (1.50 meters), regardless of age. Such persons will not be adequately protected by the harness system and may receive more severe injury than would otherwise be expected.

SCHROTH U.S. model harnessbelts have been tested in accordance with performance parameters of Federal Motor Vehicle Safety Standard 209 with the exception of Paragraph S 4.6 (full scale impact testing as described in FMVSS 208). FMVSS 209 deals with lap and three point restraints and does not expressly refer to harness belts. SCHROTH has nevertheless applied the performance criteria specified in FMVSS 209 to the system to the extent applicable.

These belts, when properly installed and used according to applicable instructions can mitigate injury. The ability of any restraint system to mitigate or prevent injury is directly related to the type and severity of the accident. SCHROTH asm harnessbelts have been tested in dynamic sled tests utilizing a 75 kg (165 lbs) Hybrid II anthropometric dummy to simulate head-on collisions at 50 km/h (31 mph). They also have been dynamically tested utilizing a 75 kg mass dummy in accordance with European Safety Standard ECE-R 16.04.

PACKAGE CONTENTS

The contents of each package is as detailed in the table below for each belt.

VW/Audi Rallye 4 Left		VW/AUDI Rallye 4 Right	
VW/Audi Left Belt	1x	VW/AUDI Right Belt	1x
Left side lap belt connector	1x	Right side lap belt connector	1x
Left side tail strap connector	1x	Right side tail strap connector	1x
7/16" Bolt	1x	7/16" Bolt	1x
Washer	1x	Washer	1x
Spacer	1x	Spacer	1x
SCHROTH asm sticker	1x	SCHROTH asm sticker	1x
SCHROTH Racing sticker	1x	SCHROTH Racing sticker	1x
VW/Audi Rallye 4 Install Inst.	1x	VW/Audi Rallye 4 Install Inst.	1x

MANUFACTURING INFORMATION

Each SCHROTH belt is manufactured to exacting standards. Specific manufacturing information of each belt is printed on the back side of the plastic **asm** cartridge cover.

US Version asm cover

Type of belt

FMVSS Certification

Importer

Date of manufacture

Product number



SAFETY INSTRUCTIONS

Always keep this manual in the vehicle so that others can thoroughly familiarize themselves with the proper use of the system.

INSTALLATION INSTRUCTIONS

1 General Instructions

Always leave original equipment seat belts in place and available for use.

We strongly recommend that you leave in place all factory provided 3-point restraint systems originally supplied for the front and rear seating positions of your vehicle when you install the SCHROTH asm harnessbelt. Removal of original equipment restraint systems may also violate applicable State or Federal law.

To carry rear seat passengers, you must use your standard 3-point factory provided front seat belts. To use the factory installed seat belts after a SCHROTH VW/Audi Rallye 4 belt has been installed you must first release (un-clip) all four points of the SCHROTH belt and remove it.

Leaving original equipment restraint systems in place and fully functional will enable you to choose either the SCHROTH


Rallye 4 OR the vehicle's standard seat belts when it is necessary to transport passengers in any of the rear seats or when either harness belt is not suited for use by the driver or front seat passenger.

! WARNING

When using the SCHROTH harnessbelts, folding front seat backrests will be restricted in their range of motion. Evacuation or rescue of rear seat passengers can be restricted or even impossible after an accident and severe injuries or death may occur. **DO NOT CARRY REAR SEAT PASSENGERS WHEN USING SCHROTH RALLYE BELTS.**

! WARNING

Separate SCHROTH asm harnessbelts are supplied for the left and right sides. The black "asm cartridge" must be on the inboard shoulder strap when system is installed (see illustration). Never install a belt on wrong side of vehicle. System will not function properly in an accident and serious injury or death may occur.



! WARNING


Use of improper attachment points will impair system performance. Weak tail strap anchor points will not withstand the forces in an accident and increase the risk of personal injury.

Never attach the tail strap to anchorages intended for the tether straps of child seats that are found on the filler panels behind the rear seats of some passenger cars or the luggage area of some hatchbacks or station wagons. These anchor points are not strong enough to withstand the forces of an accident and are not intended for adult belts.

Harness belt systems may only be installed at suitable anchor points for seat belt systems as originally installed by the vehicle manufacturer.

For suitable anchor points for make, model and model year of your vehicle, see Certified Vehicle List (Vehicle Reference List). If in doubt, ask your dealer to show you where these anchor points are located.

These figures show the general location and suitability of seat belt anchor points installed as standard equipment in specific VW/Audi model passenger cars.



BMW E39 5 Series 1996-2002 & E46 3 Series 1999-2002
Left Side Right Side

■ Install Schroth Tail Strap w/Male End ● BMW Factory Provided Female Receptacle

(The E39/E46 Diagram also applies to the VW/AUDI)

Green Squares represent points where SCHROTH provided male connecting tail straps are to be installed at factory mounting points along with factory provided harnessbelts.

Red Circles represent points where the SCHROTH VW/AUDI Rallye 4 belts are designed to plug into VW/AUDI factory provided seatbelt female receptacles.

a minimum of nine (9) full 360 degree turns. Tighten all anchorage bolts to a torque of 30 ft.lbs. (40 Nm)

3 Installation of SCHROTH rear outside tail strap buckles – Left & Right belts.

- ✍ Remove the rear seat bottom cushion. It will pull straight up and release with moderate force.
- ✍ Locate and remove the outermost VW/Audi lap belt anchor bolts at the outside corners just below the rear seatback bolsters.



- ✍ Bend and mount the SCHROTH tail strap connector as shown in the picture above. Be sure to replace the bolt with the SCHROTH bolt, washer as pictured above.
- ✍ Do Not re-install the seat cushion until completing the rest of the installation.

! DANGER

THIS SCHROTH VW/Audi RALLYE 4 HARNESSBELT IS ONLY DESIGNED FOR VW/AUDI MODELS AS INDICATED ON THE SEWN IN LABEL ON THE HARNESSBELT TAILSTRAP. USE IN ANY OTHER MODEL OR IN ANY OTHER AUTO OF A DIFFERENT MANUFACTURER COULD RESULT IN THE FAILURE OF THE HARNESS SYSTEM AND SERIOUS INJURY.

! DANGER

Never drill or tap or make a new attachment point in the body or chassis in order to mount a SCHROTH harness at that location. Such attachment points are inadequate, may be improperly located and can seriously impair the function and effectiveness of the system.

Please compare the mounting locations on your car with the illustration on page 6 and verify the "Model Tag" as pictured above (sewn into the tail strap) matches the model of your vehicle.

Original equipment belts with swivel attachments must never be bent, modified, impeded or restricted in their range of motion.


2 Anchorage bolts & SCHROTH Rallye Bolt on bracket

Where additional SCHROTH connecting tails are to be installed (referenced by the Green Boxes on the diagrams on page 6), the SCHROTH connector will be bolted to the a factory mounting point along with the factory belt using the factory provided bolts. You should be able to tighten each bolt

4 Installation of the outside front belt connectors

The front outboard lap belt mounting points are located behind the plastic trim at the base of the B Pillar. Working with the rear seat cushion out of the car (per step # 3), and the front seats as far forward as possible:

- ✍ Locate the lower trim panel. This panel runs the length of the interior at the junction between carpet and plastic. It is secured at the rear of the cabin via a Philips head screw.
- ✍ Remove this screw.
- ✍ There will be another mounting location a few inches forward of that screw. It releases with moderate force. Be sure to pull straight up. The clip is pictured below.



- ✂✂ Carefully remove the rest of the trim piece. It is held at the B Pillar with a tab shown below. Push down on the trim in the vicinity of the tab, forcing the tab to clear the B Pillar Trim piece.



- ✂✂ Once this tab is clear, you can remove the rest of this panel.
- ✂✂ Locate the Factory mounting location of the lap belt at the base of the B Pillar. Using a Box-End wrench or a shallow socket, Remove this bolt.
- ✂✂ Bend the SCHROTH bracket as shown in the picture below and place the SCHROTH bracket just under the bolt head.



- ✂✂ Reinstall the bolt as shown above.
- ✂✂ Before tightening the bolt, align the SCHROTH connector so that the webbing is pulling in the same

direction that the belt will pass over your lap when connected.

- ✂✂ Torque the bolt to 30 ft.lbs.
- ✂✂ Be sure to keep the Schroth tail strap accessible as you reinstall the plastic trim piece. Please take notice of the range of flexibility for the mounting tabs as shown in step 6.

5 Installation of inside lap belt and tail strap connectors


Simply plug the SCHROTH VW/Audi "male" buckles (both front and rear) into the factory provided female receptacle next to the transmission tunnel.

6 Flexible range of the seat belt mounting brackets

WARNING

Repeated bending could weaken the bracket and cause it to fail when loaded in an accident.

Never bend the bracket back and forth several times. Any pivoting brackets of the stock 3-point belts must not be limited in their range of motion.



OPERATING INSTRUCTIONS

1 General instructions

Most states require that all passengers wear seat belts when a car is in motion. Please check with your local authorities for further information! Regardless of the law in your State, it only makes sense to buckle up, so before you start your car, make sure that you and all of your passengers are properly restrained.

The SCHROTH asm harnessbelt system when properly installed and used according to applicable instructions can mitigate injury. Of course, the ability of any restraint system to mitigate or prevent injury is directly related to the type and severity of the accident.

WARNING

This product is not designed and tested to be used with HANS® or other head and neck restraints e.g. Hutchens device.

Shoulder belts may slip off the HANS® and crotch straps e.g. of a Hutchens device cannot be properly attached to the lap belt. Malfunction can result in serious personal injuries or death.

WARNING

Improper use of any seatbelt can cause serious personal injury or death.


To help reduce the risk of serious injury in an accident:

- ⚡ Never strap more than one person in place, with each harness system.
- ⚡ Never wear the harness system at the same time as the original equipment seat belts.
- ⚡ Never use the lap belt portion of the harness system without the shoulder belts.
- ⚡ Always make sure that lap belt and shoulder belts are not twisted when worn.
- ⚡ Never use the harness belt system for children under the age of 12 years or to install an infant seat or child seat.
- ⚡ Never use the harness belt system for persons who weigh less than 88 lbs or those who are less than 4'11" tall, regardless of age.
- ⚡ Always wear the lap belt portion of the harness system low and tight across the pelvis. This is also recommended for the stock 3-point belt whenever it is worn.
- ⚡ Never wear the belts over heavy clothing as it can interfere with proper positioning and adjustment of the belts, reducing the overall effectiveness of the system.
- ⚡ Never wear the belts over rigid or breakable objects in or on your clothing, such as eye glasses, pens, jewelry keys etc. as these may cause injury.
- ⚡ Never allow lap or shoulder belts to rub against sharp objects.
- ⚡ Never allow the belts to be damaged by becoming caught in door or seat hardware.

The following pictures show the correct installation and use of SCHROTH asm harnessbelts:

2 Routing of the shoulder belts

It is important to be sure to route the SCHROTH shoulder belts between the two posts of the headrest as pictured to the right.



3 QUICK FIT – ClipIn/ClipOut attachment points

Front Inside Lap Belt Mount Points

Clip the SCHROTH Lap Belt harness end with the VW/Audi male latch into the factory female receptacle as you would your stock 3-point harness.

Front Outside Lap Belt Mounting Points



Plug in the SCHROTH female receptacle on the outer end of the lap belt to the male end of the connecting strap that you bolted to the factory mounting point as pictured above.


Inside Rear Tail Strap Mount Points

Clip the SCHROTH Tail Strap end with the VW/Audi male latch into the factory female receptacle as pictured Below.



Outside Rear Tail Strap Mount Points

Plug the outside (far right or far left) tail strap with the of the SCHROTH belt with SCHROTH male buckle into the SCHROTH "separation buckle" that you bolted into chassis. Shown below:



4 Adjustment of the seating position

Choose your most comfortable seating position for safe driving.
Driving and Safety Instructors recommend:

"Select your seating position in the vehicle so that you can fully grip the upper edge of the steering wheel with your elbow still slightly bent and without moving your upper body from the seatback. With the clutch (automatic transmission-brake) fully depressed your knee should still be slightly bent."

Remember: A "laid back" seating position might look 'cool', but does not contribute in any way to better or safer handling of your vehicle! No racing or rally driver is "laid back" in his vehicle!

5 How to close and release the buckles


5.1 Lap belt buckle and all "Click-In" points where the standard BMW Female Receptacle is used.

To close: Insert the latch into the buckle until you can hear a distinct clicking sound.

To open: Depressing the red button marked "PRESS" will open the buckle.

5.2 Buckle between tail strap and the outer most rear tail strap of the shoulder belts (separation buckle).

To close: Insert the latch underneath the plastic cover until it locks in (1) and the plastic cover slides back into its normal position (2).




To open: Slide the plastic cover in the direction of the arrow to the stop (1). Tilt the latch downwards and remove it from the buckle (2).



6 How to adjust the belt

6.1 Lengthen the belt

Hold the adjuster at right angles - 90° - to the belt and pull in direction of the arrow (see illustration beside).




6.2 Shorten the belt

Pull the end of the strap in direction of the arrow (see illustration beside).



SCHROTH offers accessory adjusting grips which can make the adjustment even more convenient (see page 18, Accessories).

7 Adjustment of the headrest and initial adjustment of the tail strap



wrong way

Belts must not have any sag.

wrong way

The tail strap must not be misdirected by upholsteries or the rear seat cushions.

right way

The headrest is properly adjusted and the shoulder belts can move freely without slack.


- After choosing the correct seating position, put the belt on and adjust the lap belt so it fits tightly in the bend between the pelvic crest and the upper thigh. The release buckle should be located in the center in front of your body. If necessary, lengthen the tail strap first.
- Next adjust the shoulder belts: Make sure there is approx. 4 inches (10 cm) of loose belt protruding from each shoulder belt adjuster.
- One of the two shoulder belts should now be tight against the shoulder; the other shoulder belt should be looser.
- Tighten the looser shoulder belt until both shoulder belts have the same pressure over the shoulders and in the chest area.

Make sure the shoulder straps are properly adjusted whenever the SCHROTH harnessbelt is worn.

For lap belt adjustment see following paragraph.

8 Putting on the belt

- After choosing the correct seating position, put on the belt and adjust the lap belt so it fits tightly in the bend between the pelvic crest and the upper thigh. The release buckle should be located in the center in front of your body. (HINT- slide the seat back - tighten the lap belt – move the seat forward to maximize lap belt tightness.)



9 Use of the rear seats


WARNING

Never wear the SCHROTH harnessbelt if any rear seating position is occupied. Both front seat occupants must then use original equipment 3-point belts. The rear seat occupant could interact with the tail strap of the SCHROTH harnessbelt during an accident and cause serious injury to himself or to the wearer of the harness belt.



SAFETY INSTRUCTIONS


?? As a constant reminder, the enclosed transparent sticker must be attached to the rear side window in a prominent place. The sticker cannot be removed without damage to chromate tinted glass. On such vehicles, you may affix the transparent sticker at a different, prominent location so that it will serve as a constant reminder.



SAFETY INSTRUCTIONS

?? In order to get an even tighter fit of the lap belt, we recommend that you move your seat back a little, adjust the length of your belt as described above and move the seat forward to its normal position. This will help to tighten the lap belt even more. This recommendation applies only to two door coupe models where one lap belt mounting point is attached directly to the chassis.

- b) Adjust the length of the inboard shoulder belt until both belts exert equal pressure against the upper torso.



10 Stowing the belts when not in use

If you use the stock 3-point belt instead of the SCHROTH harnessbelt, be sure to properly stow the SCHROTH harnessbelt so that it is not exposed to seat tracks, liquids, sun light, or any other area where the belt could possibly be damaged.

When not in use we recommend that you unhook all four points and remove the entire belt for proper storage.

CARE and MAINTENANCE

1 Inspection

Check the safety belt once a month for any damage. Cuts, tears and other damage to the belt will greatly reduce its effectiveness. Replace the belt or damaged parts immediately with original Spare Parts (see page 11, Spare Parts). Never use a damaged harness belt, use the standard 3-point belts which remain available for use.

Make sure the buckles are free of any obstruction and lock securely.

WARNING

Modified belts or such belts that have been resewn are not strong enough and are dangerous in an accident.
Never modify, disassemble or repair the belts yourself.
For parts that can be replaced, use only original SCHROTH Spare Parts.
Only original SCHROTH Accessories may be used with the harness belt system.
Use of non-authorized parts and Accessories can reduce the effectiveness of the harness belt system.

SAFETY INSTRUCTIONS

?? Any changes made to the belt will automatically void the warranty.

WARNING

Never use any restraint system that does not function properly. If questions arise, immediately contact your importer or the manufacturer!

2 Accident

WARNING

A safety belt which was in use during an accident has been weakened and is unfit for further use and must be replaced! One indication that the belt was exposed to excess strain and therefore requires replacement is when the stitches of the asm-system are ripped open and are protruding from underneath the asm-plastic cover.

WARNING

A restitched asm seam is dangerous.
The asm energy conversion device may not be restitched under any circumstances.

After an accident, in addition to replacing seat belt which were in use, also be sure to ask your car dealer for carefully check all seatbelt attachment points for deformation or cracks. Always make sure that the guidelines of the car manufacturer are followed if a repair is necessary.

3 Re-assembling the length adjuster

WARNING

We do not recommend to disassemble the length adjuster during installation process. Even to run the harness belt through the openings at racing seats disassembling is not necessary.

If for any reason the length adjuster is disassembled, strictly follow the procedure step by step as described below to re-assemble the adjuster.

4 Cleaning



Figure A:

Fold the strap to a loop and insert it upwards throughout the metal frame and turn the loop as indicated.

Note:

The strap part protruding from the adjuster for further adjustment [1] must be located above the stress taking strap [2].



Figure B:

Position the plastic cover on top of the loop and insert the metal retainer [3] through the guides of the plastic cover and the strap loop.



Figure C:

Keep the metal retainer positioned between your thumb and forefinger. Slide the plastic cover backwards onto the metal frame as indicated until both ratchets [4] locks with a distinct clicking sound into the detentions in the metal frame.



Figure D:

Check by pulling both stress taking straps [2] and [2'] the adjustment device will lock safely.

To clean the belt, use soap and warm water. Do not use any solvents! Do not dry the belt in the sun or near a radiator.

WARNING

Improper cleaning or drying of the harness belts can weaken them, reduce their effectiveness and can result in serious personal injury or death.

5 Installation Accessories

Color key:

black=0, blue=1, red=2, yellow=3, purple=5, green=8

The X in PINs must be substituted by the color key of the color you want to order!

Shoulder belt pads, pair of	black with yellow flock printing	00109
Shoulder belt pads, pair of	blue with black flock printing	01109
	red, yellow, purple, green with black flock printing	0X109
Shoulder belt pads, pair of	black with gray flock printing	09109
Shoulder belt pads, pair of	silver-gray w. black flock printing	09209
Shoulder belt pads, pair of	black with black flock printing	09309
Adjusting grips for length adjuster, 4 pcs./package		00092

6 Spare Parts

If any part of your harness needs replacement, please contact your nearest dealer. USE ONLY GENUINE SCHROTH PARTS.

Cover for adjuster inclusive retainer	01084
---------------------------------------	-------

7 VW/Audi Quick-Fit Part Numbers

Verify you have the correct belt for your car. The following part numbers apply only to VW/Audi Quick-Fit Rallye 4 Belts.

VW/Audi Quick Fit Rallye 4	Black Left	16160
VW/Audi Quick Fit Rallye 4	Black Right	16660
VW/Audi Quick Fit Rallye 4	Blue Left	16161
VW/Audi Quick Fit Rallye 4	Blue Right	16661
VW/Audi Quick Fit Rallye 4	Red Left	16162
VW/Audi Quick Fit Rallye 4	Red Right	16662
VW/Audi Quick Fit Rallye 4	Silver Left	16169
VW/Audi Quick Fit Rallye 4	Silver Right	16669

We reserve the right to incorporate any technical changes or further development in this product without notice.

If you need additional information or have any comments or questions about the SCHROTH asm harnessbelts, please contact your dealer or the importer.
[see www.schroth.com]

In North America please contact:

MDI/Schroth
A DIVISION OF HMS MOTORSPORT, LTD.
3 First Avenue
Peabody, MA 01960
Toll Free (888) 536-8550
Phone (978) 532-1145
Fax (978) 532-2016

To locate your nearest dealer call:
(800) 884-BELT

REMEMBER:

For safety's sake, always buckle up.

SCHROTH and **SCHROTH-asm®** are registered trademarks of SCHROTH Safety Products GmbH, Germany.

The SCHROTH-asm® safety system is patented in several European countries, the United States and Japan.

The copyrights of this Installation and Operating manual are property of SCHROTH Safety Products GmbH, Germany.

Copyright of this part or in whole, on paper, on film or electronically is allowed only after written permission by SCHROTH Safety Products GmbH, Germany.

© 2003, SCHROTH Safety Products GmbH, Arnsberg, Germany.

Legend to Vehicle Reference List

Heed all Indexes! - Symbols and #'s must be followed !

+ VW / Audi quick fit belt can be installed without vehicle alteration.

S Stock seat not approved. For installation of tail strap to this anchor point, use only special seats, tested and approved by SCHROTH.
For SCHROTH tested and approved special seats see list below.

10) Index "S" do not refer to vehicles equipped with RECARO front seats ("sport seats").

27) To avoid release of the pyrotechnic seat pretensioning devices the battery has to be disconnected 10 minutes before starting installation.

35) If stock 3-point belt should be removed from the car **never** remove stock seat belt buckle as there is a safety device included (VW-description: lunar module) which **never** must be removed from the car.

List of Approved Special Seats

COBRA SUPAFORM: Cobra S, Instyle/LS, Montreaux

CORBEAU EQUIPE: Avanti Recliner, GTB Recliner, GTS Recliner

FLOFIT: Flofit-Sport

KEIPER RECARO: Orthopäd (Orthopedic), Designer Touring (design touring), Idealsitz SR, L, LX, LS 84, CS 84, CSE, T-Line, Designer Sport (design sport), C-Classic, TX, N, LS, CT, Variomed, A 8

KÖNIG: K330/370, K430/470, K530/570, K630/670, K730/770, K830/870, KS400/4000/700, CP400/4000/700, P700, RL200, CL200/400, RS/RSL 4400/8800

Be sure to contact your local Cobra, Corbeau, Flofit, König or Recaro dealer for information regarding seats recommended for the make, model and model year of your car.

Vehicle Reference List

SCHROTH VW / AUDI Quick Fit Belt

Make Model	Model No.	Mod. Year	VW/ AUDI QuickFit Belt
AUDI			
4000	81	1980 - 1987	S
5000	43	1980 - 1983	S
5000 wagon	43	1980 - 1983	S
5000, -turbo	44	1982 - 1988	+
5000 quattro, -turbo quattro	44 Q	1984 - 1988	+
100, 200	44	1988 - 1991	+
Coupé, GT	85	1982 - 1987	S
Coupé, 4000 CS quattro, 80, 90	89	1988 - 1989	+
not Audi Quattro			
V 8	D11	1988 - 1994	+
A4 ²⁷⁾	B5	1994 - 2001	+
A6 ²⁷⁾		1994 - 2002	+
VOLKSWAGEN			
Beetle	11	1960 - 1979	S
Rabbit	17	1975 - 1984	S
New Beetle ²⁷⁾ , ³⁵⁾	1C	1998 -	+
New Beetle Cabrio ²⁷⁾ , ³⁵⁾		2002 -	+
Jetta I		1980 - 1984	S
Scirocco I		1975 - 1981	S
Golf	17, 1G	1985 - 1992	+
Jetta II	16, 1G	1985 - 1992	+
Golf III, Jetta III	1H	1993 - 1999	+
Golf convertible	15	1980 - 1995	S ¹⁰⁾
Golf IV ²⁷⁾ , ³⁵⁾	9B	1998 -	+
Jetta IV ²⁷⁾	9M	1998 -	+
Jetta station ²⁷⁾	9M	1998 -	+
Dasher		1976 - 1981	S
Passat sedan, -station	31	1989 -	+
Scirocco II	53	1982 - 1988	S ¹⁰⁾
Corrado	50	1990 - 1995	+

For indexes see Legend of Vehicle Reference List

HMS Motorsport

3 First Avenue
Peabody, MA 01960
Toll Free (888) 536-8550
Phone (978) 532-1145
Fax (978) 532-2016

Our Service Number
(800) 884-BELT
guides you to your nearest dealer.



This belt is designed and manufactured specifically for use only in specific VW / AUDI models as listed in this vehicle reference list. Compare your car's specifications to the type no. and model year of vehicle in this vehicle reference list. Use of this belt in any other VW / AUDI model or any other make and model is strictly prohibited. Use of this belt in such vehicles can cause serious personal injuries or death in the event of an accident.

This product is not designed and tested to be used with HANS® or other head and neck restraints e.g. Hutchens device.

If stock seats with integrated side airbags or seat-based sensors are being replaced by aftermarket seats care is necessary to ensure that the entire vehicle safety systems are not compromised. Elimination of seat based airbags sensors by swapping seats could result in a faulty deployment and/or non-function of airbags and permanent illumination of dashboard airbag system warning light. Buckle-pretensioners must never be removed from the vehicle with or without the seat without being secured against unintended firing. Removing buckle-pretensioners from the car also may disturb the function of other safety devices including the front airbags. Heed all instructions and information given in the vehicle's Owner Manual. Before changing seats, check with the vehicle manufacturer to see if your factory provided seats are so equipped, and if so, what provisions and precautions are necessary to preserve factory safety systems.

For indexes see Legend of Vehicle Reference List.

For indexes see Legend of Vehicle Reference List.

06/2003